





Features

Infrared

Built-in infrared blaster and receiver.

Wireless connectivity

2.4 GHz and 5 GHz network compatibility with up to 422 Mbp/s transfer speeds. Bluetooth 5.2.

Display

High resolution touchscreen with haptic feedback.

Touch slider

Adjust volume, seek media or navigate between pages.

Buttons

Customizable backlit physical buttons.

Voice

Built-in microphone and speaker for voice control and feedback.1

Wireless charging

5W compatible wireless charging.

Battery

2400 mAh battery, with deep sleep functionality.



Button functionality

Buttons perform a default action if not configured otherwise.¹

short press

long press

Home

Navigate back to home.

Back

Navigate to the previous screen.

Power

Turn off activities.
 Device power off.

Nolume up

Volume up
Change volume up.

Volume down
Change volume down.

Directional pad

Navigate left, right, up and down with confirm/enter button in the middle.

Channel up
Change channel up.

8 Channel down
Change channel down.

9 Mute Mute active device.

n Record

Start or stop recording media.

Options
Open guide or contextual menu based on supported features.

Microphone
Voice command or speech to text input.

Backward

Skip to the previous song or chapter.

Seek backwards in media.

Stop media.

Play/pause

Forward

Stop

Play media when paused or pause media when playing.

Skip to the next song or chapter.

Seek forward in media.

Getting started

Just power on the device and follow the instructions on the screen.

You can complete the setup without downloading any apps or registering an account.

- Press the power button for 4 seconds.
- 2 Follow the on-screen instructions.

For guides and quick tips visit: unfoldedcircle.com/support



User interface

Add pages for each room in your home, or create pages for device categories. You are not locked into either option and free to organise the user interface the way you want.

- Pages
 - Tap for quick access to all of your pages.
- Quick toggle

 Tap the device's icon to toggle its state.
- Settings
 Pull down from the top to access settings.
- Devices

 Add devices or groups to pages to organise your system the way you want.



Dynamic and adaptive


Pages dynamically adapt when an activity is running. Media information and the activity name will be shown on the top of the page, so you'll know with just a glance what activities are running.

Buttons, like volume and transport controls adapt to the activity as well, so you can quickly adjust the volume while navigating on a page.

Media information

Artwork, title and progress will be shown at the top of the page with interactive controls.

Multiple activities
Switch between all running activities with just a swipe.



Activities

Combine the controls of several devices on a single screen. Add widgets to the activity, that can display media artwork, information or execute commands and show sensor data.

As easy as drag and drop, you can customise the user interface for all of your activities.


Media widget

Display artwork, title and more with the media widget.



Custom buttons

Execute a command from the screen? No problem. Just add a button widget.



Touch slider

Want more precision and quicker control than pressing a button?

With the touch slider you can easily adjust the volume, seek media or switch between pages.

- Visual feedback pops up as soon as you start sliding your finger.
- The touch slider will control the running activity or one of the selected devices' features.



Every system and home is unique.

There's no universal configuration that fits all. Remote 3 offers plenty of customisation and flexibility to help you tailor it to your needs.

For guides and quick tips visit: unfoldedcircle.com/support

